

JTSE-1A 100/120V
JTSE-2A 230V

HOT AIR STATION

SPARE PARTS

JTSE-1A / JTSE-2A

- ENCLOSURES:
- TOP 0011035
- BOTTOM 0013486
- FRONT 0016862
- BACK 0016812


JTSE-1A

- CIRCUIT 0017185
- SUCTION PUMP 0008723
- HOT AIR PUMP 0015970



JTSE-2A

- CIRCUIT 0017671
- SUCTION PUMP 0008722
- HOT AIR PUMP 0015970

JTSE-1A 100/120V FUSE T-8A
JTSE-2A 230V FUSE T-4A



0012332



0014107 (230V)
 0014105 (100V, 120V)

