

**DI-1D** 120V

**DI-2D** 230V

**DI-9D** 100V

1 TOOL CONTROL UNIT



## SPARE PARTS

### DI-1D / DI-2D / DI-9D:

-CIRCUIT	0013287
-ENCLOSURE	
· TOP	0011435
· BOTTOM	0014032
· FRONT	0013830
· BACK	0003506

DI-1D 120V FUSE T-2A  
DI-2D 230V FUSE T-1A  
DI-9D 100V FUSE T-2,5A

